


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------------------|------------|----------|------------------|------------|----------|----------------------------------|
| 1 | | LITERATURE PARTS | 13 | | Hinge Cover | 24 | | Hinge Cover |
| | 2315214 | Use & Care Guide | | 2203407W | White | | 2203408W | White |
| | 2255385 | Service & Wiring Sheet | | 2203407T | Biscuit | | 2203408T | Biscuit |
| | | | | 2203407B | Black | | 2203408B | Black |
| | 2315352 | Energy Label | 14 | 2304322 | Hinge Bottom | 25 | 549193 | Clamp, Service Cord |
| | 2220407 | Modular Ice maker Service Sheet | 15 | | Filler, Wrapper | 26 | 489084 | Screw |
| 2 | 2174748 | Front Roller (2) | | 2196094 | White | 27 | 2155311 | Door Closer, Lower Cam (2) |
| 3 | 3400517 | Screw | | 2196150 | Biscuit | 28 | 489483 | Screw |
| 4 | 2196236 | Roller (Rear) (2) | | 2196097 | Black | 29 | 489500 | Screw |
| 5 | 489427 | Screw | 16 | | Grille | 30 | | Cap, Water Filter |
| 6 | 2155013 | Clip, Grille | | 2198467W | White | | 2186494W | White |
| 7 | 489478 | Screw | | 2198467T | Biscuit | | 2186494T | Biscuit |
| 8 | 2186443 | Housing, Water Filter | | 2198467B | Black | | 2186494B | Black |
| 9 | 2209697 | Shim | 17 | 489497 | Screw | 31 | | Cabinet (Not A Serviceable Part) |
| 10 | 2203771 | Hinge Top (RC) | 18 | 489464 | Screw | 32 | 2203770 | Hinge Top (FC) |
| 11 | 8281227 | Screw | 19 | 940139 | Drain Fitting | 34 | 2255012 | Tube, Filter Outlet |
| | | | 20 | 1108438 | Extension Tube | 35 | 3400113 | Screw |
| | | | 21 | 1108439 | Clip, Drain Tube | 36 | 2304697 | Tube, Filter Inlet |
| | | | 22 | 2255519 | Water Filter | | | |
| | | | 23 | 2204202 | Cover, Unit | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------------------------|
| 1 | | Liner (Not A Serviceable Part) |
| 2 | 2255612 | Escutcheon, Meat Pan Control |
| 3 | 2301339 | Slide Meat Pan Control |
| 4 | 2257741 | Louver |
| 5 | 2205813 | Strap |
| 6 | 2256035 | Bracket, Dual Crisper Lights |
| 7 | 2256037 | Wire Harness, Dual Crisper Lights |
| 9 | 2206270 | Shelf Ladder |
| 10 | 489478 | Screw |
| 11 | 486298 | Screw (2) |
| 12 | 2179404 | Rack, Wine & Egg |
| 13 | 1123919 | Bracket, Retainer |
| 14 | 489290 | Screw |
| 15 | 2209753 | Air Diffuser Assembly |
| 16 | 2152019 | Air Diffuser Cover |
| 17 | 2150331 | Cover, Conduit |
| 18 | 2162085 | Socket |
| 19 | 2256126 | Reservoir |
| 20 | 2255743 | Light Bulb |
| 21 | 2209769 | Light Lens |
| 22 | 488280 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---------------------------------------|
| 1 | 2182119 | Fan Scroll |
| 2 | 2155590 | Retainer, Fan Motor |
| 3 | 2198595 | Air Scoop |
| 4 | 2212377 | Air Duct, Upper |
| 5 | 2212313 | Air Duct Freezer |
| 6 | 2188824 | Bi-Metal, Defrost |
| 7 | 2220569 | Fan Motor |
| 8 | 2169142 | Fan Blade |
| 10 | 2176759 | Fan Grommet (2) |
| 12 | 2310111 | Harness, Fan Evaporator (Includes #6) |
| 13 | 2155788 | Gasket, Cover |
| 14 | 2172840 | Wire Tie |
| 16 | 2203875 | Gasket |
| 17 | 2212314 | Cover, Evaporator (Includes #13) |
| 18 | 8281159 | Screw |
| 21 | 489478 | Screw |
| 22 | 2203595 | Support, R.S |
| 23 | 2203596 | Support, L.S |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--------------------------------|
| 1 | | Liner (Not A Serviceable Part) |
| 7 | | Track, Basket-Dual |
| | 2301291 | Right |
| | 2301292 | Left |
| 9 | 2211743K | Shelf, Slide Out Lower |
| 10 | 2301192 | Basket, Tall |
| 12 | 2305582K | Basket Front |
| 13 | | Track, Basket |
| | 2301289 | Right Side |
| | 2301290 | Left Side |
| 14 | 2212343K | Shelf (2) |
| 15 | 2301193 | Basket, Sloped |
| 16 | 486298 | Screw |
| 17 | 842534 | Clip, Air Duct (2) |
| 19 | 2198587 | Cover, Emitter |
| 22 | 2198635 | Spring |
| 23 | 2198634 | Pin |
| 25 | 1115373 | Switch, Rocker Arm |
| 26 | 2220398 | P.C. Board |
| | | Emitter |
| 27 | 2255591 | Cover, Ice Maker |
| 28 | 2212321 | Slide, Ice Maker |
| 29 | 489478 | Screw |
| 30 | 489214 | Screw |
| 32 | 2162085 | Light Socket |
| 33 | 2255743 | Light Bulb |
| 34 | 8281185 | Screw |
| 35 | 2198633 | Flipper |
| 36 | 2255561 | Cover, Receiver |
| 37 | 2301340 | Slide, Ice Maker |
| | | Shut Off |
| 38 | 2255114 | P.C. Board, Receiver |
| 39 | 2198643 | Lens |
| 41 | 2212376 | Light Lens |
| 42 | 2198641 | Bracket, Ice Maker |
| | | Cover |
| 43 | 2155597 | Socket, Light |
| 45 | | Ladder |
| | 2212315 | Left Side |
| | 2212316 | Right Side |
| 46 | 2219878 | Shield, Wiring |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---|
| 1 | 2195975 | Frame Assembly, Slide-Out |
| 2 | 2174253 | Button, Humidity |
| 3 | 2174252 | Slide, Humidity |
| 4 | 2174273 | Gasket, Side (2) |
| 5 | 2223357 | Cover, Meat Pan (Includes 13, 14, 15 & 20) |
| 6 | 2196485 | Stud Assembly |
| 7 | 3400894 | Screw |
| 8 | 2255144 | Glass, Cover |
| 9 | 2301484 | Cover, Crisper (Includes 2, 3, 4, 11, 12, 13, 14 & 19) |
| 10 | 2255143 | Glass, Cover |
| 11 | 2223361 | Gasket (Front) |
| 12 | 2223362 | Gasket (Rear) |
| 13 | 2174478 | Eyelet, Roller |
| 14 | 2188212 | Roller |
| 15 | 489211 | Screw |
| 16 | 2301481 | Crisper Pan (Includes 13, 14 18, 19 & 21) |
| 17 | 2301482 | Meat Pan (Includes 13, 14, 19 & 22) |
| 18 | 2174076 | Window, Crisper |
| 19 | 489261 | Screw |
| 20 | 2176095 | Deflector |
| 21 | | Cap, Crisper Pan |
| | 2223286 | Right Side |
| | 2223285 | Left Side |
| 22 | 2174362 | Window, Meat Pan |
| 26 | 2206346 | Shelf Assembly |
| 27 | 2216102 | Shelf, Slide-Out Assembly |
| 29 | 2305595 | Snack Bin (Includes #30) |
| 30 | 2179243 | Trim, Handle |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


MOTOR AND ICE CONTAINER PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17

(White)

(Biscuit)

(Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|-----------------------------|
| 1 | 2212302 | Ice Bin |
| 2 | 2255583 | Crusher Bin |
| 3 | 2258224 | Auger |
| 4 | 2258220 | Washer |
| 5 | 1119007 | Spacer, Flat (4) |
| 6 | 2255461 | Cover, Crusher |
| 7 | 2257024 | Blade, Rotary |
| 8 | 1119005 | Spacer, Step (2) |
| 9 | 2257020 | Blade, Fixed |
| 10 | 2257023 | Blade, Rotary |
| 11 | 2198602 | Block, Blade |
| 12 | 489229 | Roll Pin |
| 13 | 2257022 | Blade, Rotary |
| 14 | 489235 | Washer, Plain |
| 15 | 2198661 | Washer, Coupling |
| 16 | 2220457 | Coupling |
| 17 | 8281164 | Screw |
| 18 | 3400065 | Screw |
| 20 | 2301346 | Latch, Bin |
| 21 | 2198608 | Spring, Latch |
| 23 | 8281163 | Screw |
| 24 | 2212369 | Holder |
| 25 | 2220458 | Coupling, Bottom |
| 26 | 2198628 | Seal |
| 27 | 2212370 | Washer |
| 29 | 2198607 | Spring |
| 30 | 999536 | Drive Shaft |
| 31 | 2256154 | Enclosure, Motor |
| 32 | 2212363 | Dispenser, Motor |
| 33 | 2212305 | Cover |
| 35 | 489478 | Screw |
| 36 | 2212365 | Sleeve, Coupling |
| 100 | 2258230 | Ice Container (Complete) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---|
| 1 | | Refrigerator Door (Includes Item #8) |
| | 2301188W | White |
| | 2301188T | Biscuit |
| | 2301188B | Black |
| 2 | 2308091 | Thimble, Top |
| 3 | 2301486 | Door, Compartment |
| 4 | 2193409K | Holder, Beverage |
| 5 | 2165792K | Dish, Butter |
| 6 | 2171063K | Door Bin (4) |
| 7 | 2159124 | Gasket |
| 8 | | Door Gasket, Magnetic |
| | 2221300 | Mist Beige |
| | 2221311 | Black |
| 9 | | Handle (Includes #11) |
| | 2304832W | White |
| | 2304832T | Biscuit |
| | 2304832B | Black |
| 10 | 3400012 | Screw |
| 11 | W10010140 | Screw |
| 12 | 2219698 | Stud |
| 13 | 488208 | Screw |
| 14 | 2182178 | Door Closer, Upper Cam |
| 15 | 489420 | Screw |
| 16 | | Bracket, Door Stop |
| | 2206629 | Chrome |
| | 2206629B | Black |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--|
| 1 | | Freezer Door (Includes Item #8 And Dispenser Front Parts) |
| | 2255406W | White |
| | 2255406T | Biscuit |
| | 2255406B | Black |
| 2 | | Handle (Includes #4) |
| | 2304832W | White |
| | 2304832T | Biscuit |
| | 2304832B | Black |
| 3 | 489000 | Screw |
| 4 | W10010140 | Screw |
| 5 | 488208 | Screw |
| 6 | 2171071K | Trivet, Shelf (3) |
| 7 | 2182181 | Thimble, Top |
| 8 | | Door Gasket, Magnetic |
| | 2221301 | Mist Beige |
| | 2221312 | Black |
| 9 | 2212375 | Trim, Door Shelf |
| 10 | 3400012 | Screw |
| 11 | 2207213 | Wire Harness |
| 12 | 2182179 | Door Closer, Upper Cam |
| 13 | 489420 | Screw |
| 14 | | Bracket, Door Stop |
| | 2206629 | Chrome |
| | 2206629B | Black |
| 16 | 2154473 | Connector |
| 17 | 2219698 | Stud |

DISPENSER FRONT PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--|
| 1 | | Housing, Dispenser (Not Serviced) |
| 2 | 3196537 | Screw |
| 3 | 2194719 | Retainer, Levers |
| 4 | 2180209 | Spring, Torsion |
| 5 | 2196195 | Pin |
| 6 | 2180353 | Door, Ice |
| 7 | 2304355 | Door Mechanism Assembly |
| 8 | 2205686 | Mechanism Delay |
| 9 | | Grille, Overflow |
| | 2206671W | White |
| | 2206671T | Biscuit |
| | 2206671B | Black |
| 10 | 2304317 | Water Fitting Assembly (Includes Water Tube) |
| 11 | | Lever, Ice Dispenser |
| | 2180259 | White |
| | 2186850 | Biscuit |
| | 2180261 | Black |
| 12 | 2180224 | Guide, Ice |
| 13 | 2180200 | Lamp Holder |
| 14 | 2162361 | Switch (2) |
| 15 | 2183771 | Bracket, Control |
| 16 | 3406124 | Bulb, Light |
| 17 | | Lever, Water Dispenser |
| | 2180268 | White |
| | 2186852 | Biscuit |
| | 2180270 | Black |
| 18 | | Switch Assembly (Not Available Order #23) |
| 19 | | Overlay, Front Cover (Not Available Order #23) |
| 20 | 2187406 | Wire Assembly |
| 21 | | Front Cover, Housing (Not Available, Order #23) |
| 22 | 489000 | Screw |
| 23 | | Front Cover Assembly (Includes Items 18, 19, 20 & 21) |
| | 2207349W | White |
| | 2207349T | Biscuit |
| | 2207349B | Black |
| 24 | 2304673 | Bracket, Dispenser |
| 25 | 2195051 | Strain Relief |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)


| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|----------|---|------------|----------|--|---|----------|-----------------------|
| 2 | 2225834 | Fan, Blade | 20 | 2182057 | Unit Cover, Bottom | 55 | 489478 | Screw |
| 3 | 2223953 | Condenser Assembly | 21 | 489396 | Clip | 59 | 2208280 | Clip, Wire & Tube |
| 4 | 489464 | Screw | 22 | 2188822 | Evaporator | 63 | 2209709 | Connector, Water Tube |
| 5 | 2216914 | Clip, Condenser | 24 | 2188874 | Motor, Fan | Following Parts Not Illustrated and Optional Parts Not Included | | |
| 6 | 8533993 | Screw (2) | 25 | 1105523 | Tray, Evaporator | | | |
| 7 | 2304288 | Heat Shield And Drain Pan | 26 | 2187783 | Harness, Wire | | | |
| 8 | 2205764 | Tube Suction | 27 | | Drier | | | |
| 9 | 2183454 | Relay (Service Only) | | 2199167 | Production | | | |
| 10 | 2223314 | Clip, Retaining | | 4387019 | Service | | | |
| 12 | 4387731 | Cover (Service Only) | 28 | 2212191 | Compressor (Includes Items 9, 12, 13, 17, 18, 27 & 39) | 978025 | | Valve, Access (1/4") |
| 13 | 2187145 | Overload (Service Only) | 30 | 2160501 | Frame, Unit Mounting | 978026 | | Valve, Access (5/16") |
| 14 | 2161324 | Clip, Defrost Heater | 32 | 2181929 | Bracket, Fan Motor | 978027 | | Valve, Access (3/8") |
| 15 | 2261599 | Tube, Condenser to Heat Loop | 33 | 2188174 | Heater, Defrost | 978028 | | Valve, Access (1/2") |
| 16 | 2188829 | Start-Device, Combination (Start Relay and Overload for Production Compressor Only) | 34 | 2304287 | Clip | 978029 | | Valve, Access (5/8") |
| 17 | | Capacitor | 37 | 489373 | Screw | 978030 | | Valve, Access (3/4") |
| | 2169373 | Production | 39 | | Grommet (4) | 876764 | | Valve, Access (3/16") |
| | 4387764 | Service | | 1100826 | Production | REFRIGERANT CHARGE | | |
| 18 | 4387765 | Wire, Capacitor (Service Only) | | 4387558 | Service | | | |
| | | | 40 | 489340 | Screw | 5.0 oz. (R-134) | | |
| | | | 41 | 2196202 | Air Baffle | | | |
| | | | 42 | 2155547 | Clip, Heat | | | |
| | | | 48 | 2149718 | Unit Mounting Rail | | | |
| | | | 49 | 8281232 | Screw | | | |
| | | | 50 | 2186496 | Guard, Fan | | | |
| | | | 51 | 2161302 | Sleeve | | | |
| | | | 52 | 2172840 | Wire Tie | | | |
| | | | 53 | 489427 | Screw | | | |
| | | | | | | | | |



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


ICEMAKER PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---|
| 1 | 489084 | Screw |
| 2 | 2256095 | Fitting, Water Tube |
| 5 | 628379 | Clip, Fuse |
| 9 | 489478 | Screw |
| 10 | 2304834 | Valve, Solenoid |
| 16 | 489385 | Clamp, Tube |
| 18 | 2174358 | Cover |
| 19 | 488649 | Screw |
| 20 | 2212351 | Mold & Heater Assembly (Also Order 542638 Silicone Grease) |
| 22 | 628356 | Cup-Water Fill |
| 23 | 2212320 | Ejector |
| 24 | 2212318 | Ice Striper |
| 25 | 2194712 | Support |
| 26 | 627796 | Retainer, Thermostat |
| 27 | 627985 | Thermostat (Also Order 542369 Cement Alumilastic) |
| 28 | 8533917 | Screw |
| 30 | 489276 | Screw |
| 32 | 2187484 | Harness, Wiring |
| 33 | 2212317 | Bracket, Ice maker Mounting |
| 35 | 626680 | Module Assembly (Includes Items 37 & 38) |
| 37 | | Motor |
| 38 | 489136 | Screw |
| 100 | 2212352 | Complete Ice maker Assembly |

CONTROL PARTS

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------|
| 1 | 8201785 | Control Box |
| 2 | 2196001 | Tube Barrier, Thermostat |
| 3 | 489214 | Screw (3) |
| 4 | 2149705 | Light Switch |
| 5 | 2315562 | Thermostat |
| 6 | 2303822 | Electronic Control |
| 7 | 489398 | Screw (2) |
| 8 | 2200096 | Cover, Light Lens |
| 9 | 2161306 | Pivot Arm |
| 10 | 940014 | Hole Plug |
| 11 | 2172906 | Grommet, Light Bar |
| 12 | 2161466 | Slide, Thermostat |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------|
| 13 | 489084 | Screw (2) |
| 14 | 2179920 | Light Bar |
| 15 | 2172931 | Heat Shield |
| 16 | 489290 | Screw (2) |
| 17 | 2162085 | Light Socket |
| 18 | 2255743 | Light Bulb |
| 19 | 2213462 | Harness, Indicator Light |
| 20 | 2212237 | Harness, Control Box |
| 21 | 2175513 | Window |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------------------|
| 22 | 1115375 | Clip, Wiring |
| 23 | 2181741 | Slide, Air Control |
| 24 | 489391 | Fastener, Push-On |
| 25 | 2255616 | Escutcheon, Control Box |
| 26 | 2179921 | Light Bar |
| 27 | 627068 | Screw |
| 29 | 489203 | Washer, Spring |
| 30 | 2161307 | Connecting Rod, (Short) |
| 31 | 2161308 | Connecting Rod, (Long) |
| 32 | 1115374 | Clip, Wiring |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KSRG22FKWH17, KSRG22FKBT17, KSRG22FKBL17
(White) (Biscuit) (Black)

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

PAINT, PRESSURIZED SPRAY (12 oz.)

| | | |
|--|----------|---------------|
| | *350942 | Primer, White |
| | *350939 | Black |
| | *350930 | White |
| | *4392901 | Biscuit |

PAINT, TOUCH-UP (1/2oz.)

| | | |
|--|---------|---------|
| | 72017 | White |
| | 72032 | Black |
| | 4392899 | Biscuit |

***Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

PAINT, BULK (1 qt.)

| | | |
|--|---------|---------|
| | 799340 | Black |
| | 799344 | White |
| | 4392900 | Biscuit |

Miscellaneous

| | | |
|--|--------|---|
| | 212643 | Sealer, Gum (4 Feet) |
| | 479502 | Tape, Vinyl (3/4 x 108") |
| | 505587 | Sealer, Mastic (1 Qt.) |
| | 503695 | Cork, Sealer (1/4 Pound) |
| | 542638 | Grease, Silicone (1/2 Oz.) |
| | 542639 | Cement, Alumilastic (1-1/4 Oz.) |
| | 799833 | Kit, Evaporator Repair (Aluminum Epoxy) |
| | 833938 | Kit, Terminal Connector |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

TORX SCREW WRENCH

| | | |
|--|---------|----------|
| | 1117510 | Torx Key |
|--|---------|----------|